10 YEAR MANUFACTURER'S

LIMITED WARRANTY

All parts of this Kingston Brass faucet are warranted to the original retail purchaser to be free from defects in material and workmanship for a period of Ten(10) years from the date of purchase as shown on the purchaser's receipt.

This warranty is limited to defective parts only, labor charges and/or damage resulting from improper installation, repair or replacements, as well as incidental and consequential damages connected therewith are excluded.

Any damage to this faucet as a result of misuse, abuse, neglect, accident, or improper installation or any use not consistent with the instructions furnished by us, will void this warranty.

Replacement parts can be obtained from your local dealer. Freight cost is not covered by manufacturer.


CAUTION!!!

- 1. Water lines must be completely flushed before use, to avoid debris & clogs in your water system leading to mal-function and reduction of water flow.
- 2. Warranty to be void if water lines are not flushed before use of new faucet.
- 3. Use of abrasives of any strength may damage the finish of your faucet and void this warranty.


PROBLEMS SHOOTING		
PROBLEM	CAUSE	CORRECTIVE ACTION
Leaks underneath handle	Bonnet nut has come loose	Remove the handle and tightening the bonnet nut
Leaks from the spout	Valve seat and spring are worn	Replace the valve seat and spring
Inconsistent water flow pattern	Aerator is dirty or aged	Release aerator and check on rubber gasket if aged or replace with new aerator
Faucet is dirty	Caused by stubborn water spot	Clean with mild soap and warm water as often as possible
Handles works backward	Handle install backward	Rotate the right stem stop assembly 180 degrees

CODE APPROVAL: LA#M-000018





Parts:



www.kingstonbrass.com

TOLL-FREE CUSTOMER SERVICE: 1-877-2-KBRASS TECHNICAL SUPPORT E-mail: service@kingstonbrass.com


12775 Reservoir Street, Chino, CA91710




INSTALLATION INSTRUCTIONS For use With KB's Single Handle Kitchen Faucet with Sprayer

BEFORE BEGINNING INSTALLATION


- 1. Flush plumbing lines to clear debris in pipe and plumbing lines to avoid existing clogs into waterway & cartridge system of new faucet fixture.
- 2. Shut off both supply lines after flushing




1. Shut off hot and cold water supply under sink. Plug sink drain with cloth to avoid losing small parts. Remove old faucet.




2. Set the faucet in place, insert the inlet shank through the sink hole, and press down. Assemble the washers and locknut on the inlet shank, and then tighten the nut with hand. Secure this faucet tightly onto the counter with the metal nut underneath the counter as shown on this diagram.




 Install Sprayer: Insert hose guide through guide flange and snap into place. Install guide through sink and attach with mounting nut.



4. Attached sprayer head, to hose, and hand tighten only. Plumbers tape is not required. Drop sprayer hose through hose guide and let it rest in place.






- 5. Water Line Connections
- A. Connect hot and cold water supply line to faucet. B. Connect sprayer hose to the partially threaded
- inlet stem on the faucet valve.

Tighten all connections securely with a wrench. Be careful not to over tighten.


CAUTION: If faucet supply lines need to be bent, grip tubes at point of bending and slowly pull tube into position. Extreme care must be exercised. Kinked tubes will void the warranty.



6. Turn on water supply valves and check for leaks, especially at hook-ups to supply lines.

NOTE 1: If additional adapters or supply tubes are required, you can purchase them from the store where you bought the faucet.

NOTE 2: Adapter parts are not included in the package



7. Remove the aerator before turning on your new faucet for the first time. This is to prevent any deposits from clogging your aerator. Allow both hot and cold water to run for one minute. Replace aerator.